

Valves and connectors for Serres canisters

- On-off valve can be used to open and close suction. It replaces the grey angle connector.
- Serres valve is used to open and close suction when the smoke filter is used.
- T-connector is used in serial connections and can replace the Serres valve when the smoke filter is used.
- The reusable Angle connector is available as a spare part if it is disposed of accidentally.



Product no.	Product name	Packing size
57958	Serres valve	10
57618	Angle connector	20